

Getting started with ProSimPlus®

Case 8: Case studies and Specifications


This document presents the **case study** tool, which is used to analyze the influence of input parameters on the process output results. In addition, this tool helps identify the right process parameters to adjust in order to meet target **specifications** and optimize the process performance.

Summary of this Getting Started:


- 1) Introduction of the concepts and the application example
- 2) How to create a **Case Study**
- 3) How to set **Specifications**

This document presents the **case study** tool, which is used to analyze the influence of input parameters on the process output results. In addition, this tool helps identify the right process parameters to adjust in order to meet target **specifications** and optimize the process performance.

Concept of Case study




Nominal simulation





Case Study

This document presents the **case study** tool, which is used to analyze the influence of input parameters on the process output results. In addition, this tool helps identify the right process parameters to adjust in order to meet target **specifications** and optimize the process performance.


Concept of Case study



Nominal simulation



Case Study



This document presents the **case study** tool, which is used to analyze the influence of input parameters on the process output results. In addition, this tool helps identify the right process parameters to adjust in order to meet target **specifications** and optimize the process performance.

Using the data generated from the **Case study**, users can determine the specific heat duty required to achieve a desired outlet temperature and use it as a specification for the process. This approach enables fine-tuning of the heat duty parameter to meet the target conditions.


Note on terminology:

X = Input parameter

Y = Output result = target result



Process specifications




Presentation of example

The example used in this Getting Started to practice with the **Case study** and **Specification** features involves separating a hydrocarbon mixture into light and heavy components.



It is located in the ProSimPlus examples directory under the name 'PSPS_EX_EN-Simple-Example'




Presentation of example

The example used in this Getting Started to practice with the **Case study** and **Specification** features involves separating a hydrocarbon mixture into light and heavy components.



It is located in the ProSimPlus examples directory under the name '*PSPS_EX_EN-Simple-Example*'

Initial feeding & cooling:
Hydrocarbon mixture (C1) is cooled to 15°C (C2).




Presentation of example

The example used in this Getting Started to practice with the **Case study** and **Specification** features involves separating a hydrocarbon mixture into light and heavy components.



It is located in the ProSimPlus examples directory under the name '*PSPS_EX_EN-Simple-Example*'




Mixing & pressure adjustment: C2 is combined with recycle stream (C8), then pressure is dropped by 0.3 atm via expansion valve (not shown here) and sent to the flash drum (C3 to S101).

Presentation of example

The example used in this Getting Started to practice with the **Case study** and **Specification** features involves separating a hydrocarbon mixture into light and heavy components.



It is located in the ProSimPlus examples directory under the name '*PSPS_EX_EN-Simple-Example*'



Presentation of example


The example used in this Getting Started to practice with the **Case study** and **Specification** features involves separating a hydrocarbon mixture into light and heavy components.



It is located in the ProSimPlus examples directory under the name 'PSPS_EX_EN-Simple-Example'

Vapor processing: Vapor (C5) is cooled to -60°C and expanded to 25 atm in a flash drum (S102). It also allows to recover the light components in the vapor phase.

Condensate recycling: Condensates (C7) are pressurized to 75 atm via a pump (P101) for recycling to the first flash drum (S101).



Presentation of example

The example used in this Getting Started to practice with the **Case study** and **Specification** features involves separating a hydrocarbon mixture into light and heavy components.




It is located in the ProSimPlus examples directory under the name '*PSPS_EX_EN-Simple-Example*'

All the unit operations and input flow for the *Simple-Example* have been configured. So, at this point, no additional input is required from the user




Before making any modifications, the simulation can be run to verify the results.



Objective of the case study

Investigate the effect of varying the **temperature** of Flash S102 (input parameter) on the **propane mass fraction** (target result) in the lights stream. Identify the temperature at which a propane concentration of **5000 ppm** is achieved.



Conditions



Input parameter

- X = Vary the flash S102 **temperature** between -100°C and 0°C (5°C step)



Target result


- Y= **Propane** mass vapor phase composition leaving the flash



Graph plotting

- Evolution of propane composition as a function of the flash drum (S102) temperature

Creation of a Case Study: Let's do it!



- 1 Click on the “Case Study” button and select the “Case Study” option

Practical Example



2

Fill the case study parameters

Case study

Parameter

Unit operation: S102 (Liquid-vapor separator)

Parameter: Temperature

Unit: °C

Initial value: -100 Step: 5

Final value: 0 Number of points: 21

Monitoring

Filter by


Type: All types Unit operation: All unit operations

<< Prev. Next >> 1 variable selected

Selected	Variable	Form	Compounds	Stages
<input type="checkbox"/>	Vapor fraction of stream C7			
<input type="checkbox"/>	Duty exchanged			
<input type="checkbox"/>	Vapor fraction (molar)			
<input type="checkbox"/>	Liquid phase compositions	Molar	All	
<input checked="" type="checkbox"/>	Vapor phase compositions	Weight	A selection	
<input type="checkbox"/>	Flowrate of stream C8	Molar		
<input type="checkbox"/>	Temperature of stream C8			

Ok Cancel

Practical Example




A. The panel displays the number of input parameters being varied

2 Fill the case study parameters



If necessary, the green button allows the addition of new input parameters


Practical Example



B. Selection of the unit operation to be studied.

2 Fill the case study parameters

Practical Example



- C. Selection of the **input parameter** within the list of parameters available for the selected unit operation.

2 Fill the case study parameters

Practical Example



Case study

Parameter

Unit operation: S102 (Liquid-vapor separator)

Parameter: Temperature

Unit: °C

K

°C

°F

°R

D. Specification of the **unit** for the input parameter.

2 Fill the case study parameters

Practical Example



Case study

Parameter

Unit operation: S102 (Liquid-vapor separator)

Parameter: Temperature

Unit: °C

Initial value: -100 Step: 5

Final value: 0 Number of points: 21

2 Fill the case study parameters

E. This section allows to specify the variation range:

- **Initial and final value:** define the range within which the input parameter will vary for the case study.
- **Step and number of points:** specify how the variation is discretized, *i.e.*: the increment between values and the total number of points considered.



Clicking on the blue button:
Calculation of the respective value according to the 3 other given parameters



The 4 values are **consistent**

Practical Example



Case study

Parameter

+ Unit operation: S102 (Liquid-vapor separator)

1 Parameter: Temperature

Unit: °C

Initial value: -100 Step: 5

Final value: 0 Number of points: 21

Monitoring

Filter by

Type: Liquid-vapor separator
 All types
 Process feed
 Cooler/Heater
 Liquid-vapor separator
 Pump
 Stream mixer

Unit operation: S102
 All unit operations
 S101
 S102

2

Fill the case study parameters

- F. Next, the results to monitor can be selected, with filtering options available (filter by unit operation type or unit operation name).



Case study

Parameter

Unit operation: S102 (Liquid-vapor separator)

Parameter: Temperature

Unit: °C

Initial value: -100 Step: 5

Final value: 0 Number of points: 21

Monitoring

Filter by

Type: Liquid-vapor separator Unit operation: S102

<< Prev. Next >> 1 variable selected

Selected	Variable	Form	Compounds	Stages
<input type="checkbox"/>	Vapor fraction of stream C7			
<input type="checkbox"/>	Duty exchanged			
<input type="checkbox"/>	Vapor fraction (molar)			
<input type="checkbox"/>	Liquid phase compositions	Molar	All	
<input checked="" type="checkbox"/>	Vapor phase compositions	Weight	"PROPANE"	
<input type="checkbox"/>	Flowrate of stream C8	Molar		
<input type="checkbox"/>	Temperature of stream C8			

P101

Flowrate of stream C8

Temperature of stream C8

Selection

All

Selection

NITROGEN

METHANE

ETHANE

PROPANE

n-BUTANE

n-PENTANE

n-HEXANE

n-HEPTANE

n-OCTANE

Close

Cancel

2 Fill the case study parameters

- G. This table displays each unit operation with its corresponding target results. By checking the box, the target result (vapor phase composition) is activated.

The propane component is selected

Practical Example



Case study

Parameter

+ [] Unit operation: S102 (Liquid-vapor separator)

1 [] Parameter: Temperature

Unit: °C

Initial value: -100 [] Step: 5 []

Final value: 0 [] Number of points: 21 []

Monitoring

Filter by

Type: Liquid-vapor separator Unit operation: S102

<< Prev. Next >> 1 variable selected

Selected	Variable	Form	Compounds	Stages
<input type="checkbox"/>	Vapor fraction of stream C7			
<input type="checkbox"/>	Duty exchanged			
<input type="checkbox"/>	Vapor fraction (molar)			
<input type="checkbox"/>	Liquid phase compositions	Molar	All	
<input checked="" type="checkbox"/>	Vapor phase compositions	Weight	A selection	
<input type="checkbox"/>	Flowrate of stream C8	Molar		
<input type="checkbox"/>	Temperature of stream C8			

Ok Cancel

3

Click on “OK” to run the simulation

Simulation run

Simulation progress

Time: 00:00:02,937 Display simulation times

Visual update Opacity:

Complete simulation

Case number: 12

-45 °C

- FEED
- E101
- S_01
 - Iteration: 1
 - Runs in the MCN: 2
 - Convergence criterion: 1.09723
 - Damping factor: 1.00000
 - M101
 - S101
 - S102
 - P101

> Case #9: -60 °C

> Case #10: -55 °C

> Case #11: -50 °C

> Case #12: -45 °C

Status: Print unit operations
Preparing the report

Case index for each iteration of the input parameter during the case study



Each case corresponds to a different value within the range of the studied parameter



Simulation run

Simulation progress

Time: 00:00:11,984 Display simulation times

Visual update Opacity:

Complete simulation

Unit operation	Simulation time
Case number: 21	
0 °C	
<input checked="" type="checkbox"/> FEED	00:00:00,125
<input checked="" type="checkbox"/> E101	00:00:00,125
<input checked="" type="checkbox"/> S_01	00:00:00,424
Iteration: 4	
Runs in the MCN: 5	
Convergence criterion: 7.071521E-11	
Damping factor: 1.00000	
<input checked="" type="checkbox"/> M101	00:00:00,971
<input checked="" type="checkbox"/> S101	00:00:01,361
<input checked="" type="checkbox"/> S102	00:00:01,427
<input checked="" type="checkbox"/> P101	00:00:01,268
<input checked="" type="checkbox"/> Measurement	00:00:00,199

09:48:48 : - P101
 09:48:48 : - Measurement
 09:48:48 : Preparing the report
 09:48:48 : End of simulation


Simulation ended

4

When the simulation ends, close the simulation window to open the results window, for table and graphical analysis


5 Analyze the case study results: TABLE RESULTS

Table View: Displays results as **raw data** and as **table** format for easy comparison and analysis



#	S102 Temperature (°C)	Unit	Compound	Variable	Value	Unit
1	-100	°C	PROPANE	Vapor phase compositions (weight)	0,000719047	
2	-95	°C	PROPANE	Vapor phase compositions (weight)	0,00121279	
3	-90	°C	PROPANE	Vapor phase compositions (weight)	0,00194108	
4	-85	°C	PROPANE	Vapor phase compositions (weight)	0,00301789	
5	-80	°C	PROPANE	Vapor phase compositions (weight)	0,0045987	
6	-75	°C	PROPANE	Vapor phase compositions (weight)	0,00686972	

5 Analyze the case study results: TABLE RESULTS



A

Raw Data allows to group, filter and sort: by studied variable value, compound, impacted variable, units, etc... 💡


Case study results

Raw data table

Drag a column header here to group by that column

#	S102 Temperature (°C)	Unit	Compound	Variable	Value	Unit
1	-100	°C	PROPANE	Vapor phase compositions (weight)	0,000719047	
2	-95	°C	PROPANE	Vapor phase compositions (weight)	0,00121279	
3	-90	°C	PROPANE	Vapor phase compositions (weight)	0,00194108	
4	-85	°C	PROPANE	Vapor phase compositions (weight)	0,00301789	
5	-80	°C	PROPANE	Vapor phase compositions (weight)	0,0045987	
6	-75	°C	PROPANE	Vapor phase compositions (weight)	0,00686972	

5 Analyze the case study results: TABLE RESULTS



B

Table format allows for direct use of the data due to its structured organization, unlike the raw data 


Case study results

Raw data **Table**


Transpose

S102 Temperature (°C)	S102 Vapor phase compositions (weight)
	PROPANE
-100	0,000719047
-95	0,00121279
-90	0,00194108
-85	0,00301789
-80	0,0045987
-75	0,00686972
-70	0,00999797
-65	0,014041



6 Analyze the case study results: GRAPH PLOTTING




Plot view: Displays results in a graph



6 Analyze the case study results: GRAPH PLOTTING




6 Analyze the case study results: GRAPH PLOTTING




B

Select target result (Y):
Vapor phase composition of
S102




6 Analyze the case study results: GRAPH PLOTTING




C


Filter by data series: to plot only the propane composition



6 Analyze the case study results: GRAPH PLOTTING




To change graph formatting 



For more information on the advanced graph settings [click here](#) 

Results analysis



- The graph shows that the propane mass fraction in the vapor phase (lights stream) increases with temperature, reaching the target value of 0.005 at approximately -79°C .
- The temperature could then be manually adjusted in order to reach the required propane composition.

The **next step** describes how to configure the software to automatically adjust the temperature in order to meet the specified target

For more case study features [click here](#)



Now that the **case study** has analyzed the impact of **action variables** on **target results**, we can set the **specifications** to let the software automatically adjust the action variable.




Note on terminology:


X= Input parameter = action variable

Y= Output result = target result


Now that the **case study** has analyzed the impact of **action variables** on **target results**, we can set the **specifications** to let the software automatically adjust the action variable.




Now that the **case study** has analyzed the impact of **action variables** on **target results**, we can set the **specifications** to let the software automatically adjust the action variable.




Now that the **case study** has analyzed the impact of **action variables** on **target results**, we can set the **specifications** to let the software automatically adjust the action variable.



Now that the **case study** has analyzed the impact of **action variables** on **target results**, we can set the **specifications** to let the software automatically adjust the action variable.



Why do we need specifications ?



To ensure efficient process operation and meet operational targets

This involves controlling certain action variables to satisfy constraints:
 $(\text{objective value} - \text{measured value } (x)) = 0$
 or
 $F(x) = 0$

HOW?


By transferring relevant information, including **action variables** and **target result** values, from one unit operation to another.



Each available process variable
 =
 a degree of freedom

Objective of the specification

In the simple example, adjust the Flash S102 temperature to reach 5000 ppm of propane in the “Light” stream (C6)




Objective of the Specification

In the simple example, adjust the Flash S102 temperature to reach 5000 ppm of propane in the “Light” stream


Propane composition (ppm) in Lights (C6) - 5000 ppm = 0

← **Target result = 5000 ppm (propane)**

action variable = Flash temperature



Creation of a process specification




Management of constraints and recycles,
known as “SPEC” module

Measure of different process variables


Practical Example

1 Insertion of "SPEC" and Measurement modules in the flowsheet



Practical Example

2 Reconnect the **Measurement** module to the vapor stream of the **Flash** unit (S102)



Practical Example

2 Reconnect the **Measurement** module to the vapor stream of the **Flash** unit (S102)

Change the connections

Outlet connection port:

- Measurement
 - S102
 - Vapor outlet

Select the outlet connection port (B)

Process streams:

- C1
- C2
- C3
- C4
- C5
- C6
- C7
- C8

Inlet connection port:

- M101
 - Measurement
 - Controlled stream 01
 - Controlled stream 02
 - Process outlet (lights)
 - S101
 - S102

Select the inlet connection port (C)


AAA 1

Reconnect...



Click "OK" to save the data (D)

OK Cancel

Practical Example




Practical Example




3


Reconnect the **Measurement** module to the **process outlet (lights)**



Practical Example



Practical Example



Change the connections

Outlet connection port:

- Measurement
 - Information outlet 01
 - Information outlet 02

New stream

Inlet connection port:

- Constraints and recycles
 - Measured deviation 01
 - Measured deviation 02
 - Measured deviation 03
 - Measured deviation 04
 - Measured deviation 05
 - Measured deviation 06
 - Measured deviation 07
 - Measured deviation 08
 - Measured deviation 09
 - Measured deviation 10
 - Measured deviation 11
 - Measured deviation 12

AAA 1

SPEC

Show only available connections

OK Cancel


Click "OK" to save the data

C

Practical Example

5


Connect the "SPEC" module to the Flash (S102) module



Practical Example

5

Connect the "SPEC" module to the Flash (S102) module



Change the connections

Outlet connection port: Constraints and recycles

- Action 01
- Action 02
- Action 03
- Action 04
- Action 05
- Action 06
- Action 07
- Action 08
- Action 09
- Action 10
- Action 11
- Action 12

New stream

- Information input/output 01
- Information input/output 02
- Information input/output 03
- Information input/output 04

Inlet connection port:

OK Cancel

A


B

Click "OK" to save the data

C

Practical Example

Once all information streams are connected, the required **data** can be specified



Practical Example

6 Configuration of **Measurement** module

A Double click on the **Measurement** module

B Select the parameter to measure

The measurement variable is the **target result** (mass fraction)

Practical Example

The screenshot displays the configuration of a Measurement module in a simulation software. The 'Measurement (\$MESU)' dialog box is open, showing the 'Parameters' tab. The 'Fraction' dropdown is set to 'Mass fraction', and the 'Set point for a fraction' is configured to 'Mass fraction' with a value of 0.005. A list of chemical species is shown below, with 'PROPANE' selected. The process flow diagram shows a tank with a recycle stream (S102) and a measurement point (AAA 1) connected to a 'Process outlet (lights)'. The objective function is defined as $F(x) = \text{Objective value} - \text{Measured value}(x)$. The action variable x is labeled as 'x (action variable)'. The measurement module is labeled 'Measurement' and is connected to the process outlet.

6 Configuration of Measurement module

C Enter the desired value of mass fraction of propane, which is the specification

Practical Example


The image displays the configuration of a Measurement module in a simulation software. The window title is "Measurement (\$MESU)". The "Parameters" tab is active, showing the "Fraction" set to "Mass fraction" with a value of 0.005. A list of compounds is shown, with "PROPANE" selected. The "OK" button is highlighted. The background shows a process flow diagram with a measurement module "AAA 1" and a "Process outlet (lights)". The objective function is defined as $F(x) = \text{Objective value} - \text{Measured value}(x)$, and the action variable is x .

6 Configuration of Measurement module

D Select propane as compound of interest

E Click "OK" to save the data

Practical Example



7 Configuration of information stream from Measurement to "SPEC" module

Double click on the information stream $F(x)$

A


Select the data to be sent from the Measurement module to the "SPEC" module

B

Selecting « Deviation between the measured value and the set point value » aims to satisfy the condition $F(x) = 0$



Practical Example



Practical Example

The image shows a software interface for configuring an information stream. On the left, a dialog box titled "Information stream (\$ISTR)" is open. The "Name" field contains the text $F(x)=\text{Objective value} - \text{Measured value}(x)$. The "Information type to be emitted" section has a checked option for "Deviation between the measured value and the set ...". The "Information type to be received" section has a checked option for "Automatic". The "OK" button is highlighted with a red box. On the right, a process flow diagram shows a cylindrical tank labeled "S102" with a "Measurement" block and a "Process outlet (lights)" block. An information stream labeled "F(x)" is shown connecting the "Measurement" block to the "SPEC" module (represented by a circle with "AAA 1"). A blue box highlights the formula $F(x)=\text{Objective value} - \text{Measured value}(x)$ in the diagram. A blue box highlights the variable "x (action variable)" in the diagram. A red arrow points from the "OK" button to a callout box.

7 Configuration of information stream from Measurement to "SPEC" module

Click "OK" to save the data

D

Practical Example

The diagram illustrates a process flow involving a **SPEC** (Specifications) module. The process starts with a **Process inlet (lights)** entering a tank. The tank's output goes to a **Measurement** block (AAA 1), which then feeds into a **Process outlet (lights)**. A **Measurement** block (C6) is also connected to the tank. The **SPEC** module is represented by a circle with the text "SPEC" and "Constraints and recycles" below it. It is connected to the tank via an **x (action variable)** and to the **Measurement** block (AAA 1) via an **F(x)=Objective value - Measured value(x)** signal. The equation $F(x) = 0$ is shown above the SPEC module.

The **Constraints and recycles (\$SPEC)** configuration window is shown below. It has tabs for Identification, Parameters, Scripts, Report, Streams, Notes, and Advanced parameters. The **Parameters** tab is active. The window contains the following settings:

- Module enabled:** (checked)
- Numerical methods:** Default
- Stop tests:**
 - Convergence criterion: 1E-8
 - Non evolution of criterion: 1E-7
 - Non evolution of variables: 1E-6
 - Maximum number of passages in the MCN: 100
 - Maximum number of iterations: 20
- Print:** Print every 10 iterations
- Tear streams iterative variables:**
 - Temperatures
 - Pressures
- Resume:**
 - Use of values obtained at convergence of the previous problem
- Constraints:** Parameters...
- Tear streams:** Parameters...

Buttons for **OK** and **Cancel** are at the bottom.



8 Configuration of the "SPEC" module

A Double click on the SPEC module

The "SPEC" module parameters are set to default values and do not require modification, but users can adjust them if needed.

For more information on the "SPEC" module module parameters [click here](#).

Practical Example




9 Configuration of the information stream from the "SPEC" to Flash S102 module

Double click on the x information stream (A)

Select the type of information to be sent by the "SPEC" module (B)

Information type toward or from a "SPEC" module is always "automatic" 

Practical Example



Information stream (\$ISTR1)

Name: x (acting parameter)

Desc:

Identification Parameters Notes

Impose the calculation sequence

Information type to be emitted:

Automatic

Information vector to be emitted will be automatically determined depending on the parameters of "Constraints and recycles"

Start: 0 End: 0

Information type to be received:

Operating temperature

Information vector to be emitted will be automatically determined depending on the parameters of "S102"

Start: 0 End: 0

OK Cancel

9 Configuration of the information stream from the "SPEC" to Flash S102 module

- Defined by its position in the unit block's parameter zone
- Operating temperature
 - Operating pressure
 - Temperature increment
 - Pressure drop
 - Vapor fraction
 - Heat duty to be supplied
 - Heat duty to be removed
 - Efficiency (utility)
 - Utility saturation temperature
 - Utility inlet temperature
 - Utility outlet temperature
 - Utility pressure
 - Utility saturation pressure
 - No information transmitted

IMPORTANT STEP
Select the action variable within the list of parameters

C

Practical Example

The diagram illustrates the configuration of an information stream from the "SPEC" module to the Flash S102 module. The process flow includes a measurement point (AAA 1) and a process outlet (lights). The information stream configuration window is shown with the following details:

- Name: x (acting parameter)
- Desc:
- Identification: Parameters
- Information type to be emitted: Automatic
- Information type to be received: Operating temperature
- Start: 0, End: 0
- OK button highlighted

9 Configuration of the information stream from the "SPEC" to Flash S102 module


Click "OK" to save the data

D



IMPORTANT

The **action variable** must be a **modifiable input** in the unit operation (*i.e.*, a value the user can supply in the unit operation window). If it comes from another unit operation or isn't initialized, the specification won't work.



For this example:

Module: Flash S102

Specification: propane composition in the lights stream achieved by **temperature adjustment (action variable)**

Action variable to be selected in the module: **supplied temperature**

Initialize variable: Indicate a temperature value, e.g.: -60°C

Liquid-vapor separator (\$FLAS1)

Name: S102

Desc:

Identification Parameters Scripts Report Streams Notes Advanced parameters

Operating conditions Sizing

Flash type

Constant temperature and pressure flash

Temperature | Pressure

Temperature specification

Feeds adiabatic mixing temperature

Liquid-vapor separator (\$FLAS1)

Name: S102

Desc:

Identification Parameters Scripts Report Streams Notes Advanced parameters

Operating conditions Sizing

Flash type


Constant temperature and pressure flash

Temperature | Pressure

Temperature specification

Supplied



Practical Example



- 10 Once all parameters have been provided, the simulation can be run



11 Simulation results



The information of interest:

1. Stream 1 – Propane mass fraction
2. Flash S102 Unit operation – Flash Temperature



Can be displayed by using the tag feature **123** and selecting respectively:

1. MassFraction – Compound (Propane)
2. TemperatureSpecValue

(For more information on the tag feature please consult PSPS_GS01_EN-Main-features-overview documentation)




11 Simulation results




The « SPEC » module automatically adjusted the **temperature** value (-78.98 °C) at which the flash unit S102 will have an output **mass fraction** of 0.005 (5000 ppm) for **propane**

Practical Example

11 Simulation results



This temperature matches the value observed in the **case study** (approximately -79 °C) where the propane mass fraction is 0.005.



Once your standard simulation is complete, case studies and specifications become powerful tools to deepen your understanding of the process.

Case studies allow you to explore how the system responds to varying conditions.

Specifications enable the software to automatically adjust input variables to meet defined process targets.



fives

Industry can do it



Fives ProSim S.A.S.
51, rue Ampère
Immeuble Stratège A
F-31670 Labège
France

Tel: +33 (0) 5 62 88 24 30



ProSim, Inc.
325 Chestnut Street,
Suite 800
Philadelphia, PA 19106
USA


Tel: +1 215 600 3759

www.fives-prosim.com
fives-prosim.info@fivesgroup.com


Getting started with ProSimPlus®

Case 8: APPENDICES



Graph plotting features





Copy data to clipboard





Graph plotting features





Graph plotting features



Graph plotting features



Graph plotting features



Additional calculation #1



Additional calculation #1: We can also observe the effect of the action variable (temperature in this case) on other target results:


Target results

- Stream C6 flowrate
- Stream C7 flowrate
- Heat duty exchanged within the process
- Vapor fraction (molar)



IMPORTANT

To perform this simulation, the “SPEC” module must be deactivated. This can be done by double-clicking the “SPEC” module and unchecking the ‘**Module enabled**’ option.



Monitoring

Filter by
 Type: All types Unit operation: All unit operations

<< Prev. Next >> No variable selected



Selected	Variable	Form	Compounds	Stages
+	E101			
+	S101			
-	S102			
<input checked="" type="checkbox"/>	Flowrate of stream C6	Molar		
<input type="checkbox"/>	Temperature of stream C6			
<input type="checkbox"/>	Pressure of stream C6			
<input type="checkbox"/>	Vapor fraction of stream C6			
<input checked="" type="checkbox"/>	Flowrate of stream C7	Molar		
<input type="checkbox"/>	Temperature of stream C7			
<input type="checkbox"/>	Pressure of stream C7			
<input type="checkbox"/>	Vapor fraction of stream C7			
<input type="checkbox"/>	Temperature			
<input checked="" type="checkbox"/>	Duty exchanged			
<input checked="" type="checkbox"/>	Vapor fraction (molar)			
<input type="checkbox"/>	Liquid phase compositions	Molar	All	
<input type="checkbox"/>	Vapor phase compositions	Weight	A selection	
+	P101			
+	M101			
+	Measurement			






Additional calculation #1



Additional calculation #1: We can also observe the effect of the action variable (temperature in this case) on other target results:



Plotting two variables on the same graph allows for a more comprehensive analysis of process behavior




Additional calculation #2

Additional calculation #2: Multivariable sensitivity analysis

- It allows observation of the impact of multiple action variables on the target variables.



Conditions



action variables:

X1 = Vary the flash S102 temperature between -100°C and 0°C (5°C step)

X2= Vary the flash S102 pressure between 20 atm and 30 atm (1 atm step)



Target variables:

Y= Duty exchanged, mass vapor phase composition of propane



Graph plotting

Varying temperature and pressure

X1= -100°C to 0°C, X2=20 to 30 atm



Increasing the number of variables in the case study will extend the simulation time. This is due to the added complexity and the greater number of calculations required.



Additional calculation #2

■ Multivariable sensitivity analysis

- It allows observation of the impact of multiple action variables on the target variables.



First action variable (temperature)

Case study

Parameter

Unit operation: S102 (Liquid-vapor separator)

1

Parameter: Temperature

Unit: °C

Initial value: -100 Step: 2

Final value: 0 Number of points: 51

Second action variable (pressure)

Case study

Parameter

Unit operation: S102 (Liquid-vapor separator)

1

2

Parameter: Pressure

Unit: atm

Initial value: 20 Step: 1

Final value: 30 Number of points: 11

Case study

Parameter

Unit operation: S102 (Liquid-vapor separator)

1

2

Parameter: Pressure

Unit: atm

Initial value: 20 Step: 1

Final value: 30 Number of points: 11

Monitoring

Filter by

Type: All types Unit operation: All unit operations

<< Prev. Next >> 2 variables selected

Selected	Variable	Form	Compounds	Stages
<input type="checkbox"/>	Pressure of stream C7			
<input type="checkbox"/>	Vapor fraction of stream C7			
<input checked="" type="checkbox"/>	Duty exchanged			
<input type="checkbox"/>	Vapor fraction (molar)			
<input type="checkbox"/>	Liquid phase compositions	Molar	All	
<input checked="" type="checkbox"/>	Vapor phase compositions	Weight	A selection	

P101


M101

Ok Cancel




Additional calculation #2

Effect of the variation of temperature and pressure on the heat duty exchanged and the vapor phase composition of the flash drum S102



Through the **properties editor** the origin of the graph can be edited to correctly display the Y and Y' axis 



Practical Example - Specifications

Constraints and Recycles (\$SPEC)

Name: Spec1

Desc:

Identification Parameters Scripts Report Streams Notes Advanced parameters

Numerical Method

Successive substitution

Newton - Raphson **1**

Broyden

Default

Acceleration operator

Jacobian matrix: Finite differences

Number of iterations before an acceleration step: 2

Damping procedure: No adjustment

Damping strategy

Initial damping factor **2**: 1

Sensitivity analysis

Step size of the recycle streams variables proportional to...: the variable

Proportionality factor **3**: 0,1

Step size of the adjusted variables proportional to...: the variable

Proportionality factor: 0,1

Convergence criterion

Criterion: 1E-8

Stop Test

Non evolution of criterion: 1E-7

Non evolution of variables **4**: 1E-6

Maximum number of passages in the MCN: 20

Maximum number of iterations: 100

Print

Print every: 10 iterations

Tear streams iterative variables

Temperatures **5**

Pressures

Resume

Use of values obtained at convergence of the previous problem

Constraints **6**: Parameters...

Tear streams **7**: Parameters...

OK Cancel

Press **F1** to quickly access information about the module you're working on 

Number	Function
1	Selection of the numerical method.
2	Parameters of the method previously selected.
3	Parameters for the sensitivity analysis.
4	Convergence and stop criteria.
5	Allows to specify that the temperatures/pressures of the tear streams have to be variables of the problem.
6	Allows to specify bounds for the search interval for each action variable.
7	Enables to specify the list of tear streams to impose to the constraints and recycles management block unit, as well as bounds on the tear streams temperatures.

